



NOTES:

1. IF VALVE BOX RISER IS REQUIRED, USE PVC C900 PIPE EXTENSION AND NOTCH RISER FOR TRACER WIRE.
2. THE ACTUATING NUT FOR DEEPER VALVES SHALL BE EXTENDED TO WITHIN 4 FOOT DEPTH BELOW FINISHED GRADE.

PLUG VALVE AND BOX DETAIL